

How to Use the A/C & Heater

How to use your Fujitsu remote controller

<https://youtu.be/K5pbY61EK2E?si=Lko1NcGKNFj94az8>

1. Power On / Off

1. On the remote, press the **ON/OFF** button to power the indoor unit.
2. The display on the indoor unit (or wall-mounted monitor, if present) should light up.
3. To turn off, press **ON/OFF** again until the display goes dark.

2. Selecting Mode (Cool / Heat / Fan / Auto)

1. Press the **MODE** button.
2. Cycle through the options: **Cool, Heat, Fan, Dry, Auto** (depending on your model).
3. Stop on the mode you want; the remote and unit will show the selected mode.
 - *Cool* gives cooling.
 - *Heat* gives heating (if heat mode is supported).
 - *Fan* runs only fan.
 - *Dry* reduces humidity.
 - *Auto* lets the unit pick mode based on temperature.

3. Setting the Temperature

1. Use the **▲ (Up)** and **▼ (Down)** buttons on the remote to adjust the set temperature.
2. The selected temperature will appear on the remote display and often on the indoor unit.
3. Wait a moment — the unit will begin adjusting to match the new setting.

4. Adjusting Fan Speed

1. Press the **FAN** button.
2. Choose from the speeds available: *Low, Medium, High, or Auto*.
3. The indoor unit's fan speed will change accordingly.

5. Adjusting Airflow Direction (Swing / Louvers)

1. Press the **SWING** or **AIRFLOW** button on the remote.
2. Louvers will start to move automatically (if your unit supports swing).
3. Press again to stop at a fixed angle.
4. Some remotes let you set horizontal and/or vertical louver angles separately.

6. Setting a Timer

1. Locate the **TIMER** button on the remote.
2. Press **TIMER ON** to schedule when the unit will turn on. Use the **▲/▼** buttons to set the time.
3. Press **TIMER OFF** to schedule when the unit will turn off. Set the preferred time similarly.

4. Confirm by pressing **SET** or pushing the timer button again (depending on your model).

7. Using the “Sleep” / “Energy Save” Mode

1. Press the **SLEEP** or **ECO** button (if your remote has one).
2. The unit will gradually adjust temperature/fan speed to maintain comfort while saving energy.
3. To exit, press the mode or power button again.

8. Reset / Cancel Settings

1. To cancel a scheduled timer or mode, press the **CANCEL** button if available.
2. To reset the remote to default settings (rare feature), refer to the manual — often holds a **RESET** switch or a button combo.

9. Monitor Display / Unit Indicators

- Check the indoor unit’s display for current mode, fan speed, temperature, and any error indicators.
- If an error code appears (e.g., “E1”, “H3”), consult the unit’s user manual or technician guide.

Video Walk-Through

For a visual demo showing how to do many of these steps with a remote controller, watch this video: <https://youtu.be/K5pbY61EK2E?si=Lko1NcGKNFj94az8>